

Contents

Chapter 1: Introduction

| | |
|------------------------|---|
| Welcome | 1 |
| About the Manual | 2 |
| Checklist..... | 2 |
| Features | 3 |

Chapter 2: Installation

| | |
|--|----|
| Before You Begin | 6 |
| Mainboard Guide | 7 |
| I/O Ports Side View..... | 8 |
| Preparing the Mainboard | 9 |
| Install the Mainboard in the System Case | 17 |
| Make the External Connections | 22 |

Chapter 3: Setup

| | |
|---|----|
| About the Setup Utility | 23 |
| Standard CMOS Setup Option | 25 |
| BIOS Feature Setup Option | 26 |
| Chipset Features Option | 29 |
| Power Management Setup Option | 31 |
| PNP/PCI Configuration Option | 34 |
| Load BIOS Defaults Option..... | 36 |
| Load Setup Defaults Option | 36 |
| Integrated Peripherals Option | 36 |
| Supervisor and User Password Settings | 39 |
| IDE HDD Auto Detection Option | 40 |
| Save And Exit Setup Option..... | 40 |
| Exit Without Saving Option | 40 |

Chapter 4: Software

| | |
|--|----|
| About the Software | 41 |
| Running the Support CD-ROM..... | 43 |
| Utility Folder Installation Note | 43 |
| CMI8338 Audio Folder Installation Note | 44 |
| VIA Folder Installation Note | 45 |
| Mainboard Installation Notes..... | 47 |

| | |
|--|----|
| Appendix 1: Quick Jumper Setting Reference | 48 |
|--|----|